# Danalock V3 Homekit click commands

You can configure the Danalock via the button found in the small hole on the top of the smartlock. When you click through settings, the LED will change color according to the scheme below. When you get to the setting you want to change wait for 5 seconds and the Danalock will react to your command. This gives you plenty of time to navigate to the right command. If you make a wrong number of clicks, just stop at a number of clicks where the LED doesn't light up and wait for 5 seconds. The LED will flash red to indicate that it has timed out.

Clicks	Color	Activity
2	Yellow	Manual calibration
Start by turning the Danalock to the desired unlocked position. Start the calibration with the click command and wait for the LED to start blinking yellow. Turn the Danalock to the desired locked position while the LED blinks and click the button once to save the locked position. The Danalock will confirm with a green blink.		
If the lock doesn't receive a response from you within 30 sec the calibration will be canceled.		
3	White	Auto calibration
Start by turning the Danalock to unlocked position and lifting the handle if needed. The door has to be left open while the Danalock auto calibrates. Start the auto calibration with the click command. The Danalock will blink white while auto calibrating.		
4	Blue	Hold back latch
Toggles between 3 hold back latch settings: Off, short wait and long wait. Everytime this command is entered the setting will switch to the next option. • Off will respond with a red blink when being set, and will disable hold back latch. • Short wait will respond with short green blinks when being set, and will hold the latch back for 5 sec. • Long wait will respond with one long green blink when being set and will hold the latch back for 15 sec.		
5	Purple	Auto lock timer
Toggles between 3 auto locking settings: Off, short wait and long wait. Everytime this command is entered the setting will switch to the next option. • Off will respond with a red blink when being set, and will disable auto locking. • Short wait will respond with short green blinks when being set, and will lock after 15 sec. • Long wait will respond with one long green blink when being set and will lock after 60 sec.		
6	Cyan	End to end unlock
Everytime this command is entered the setting will switch to the next option. • Turning off will respond with one red blink when being set. • Turning on will respond with one green blink when being set.		
8	Blue/Green blink	Twist assist
Everytime this command is entered the setting will switch to the next option. • Turning off will respond with one red blink when being set. • Turning on will respond with one green blink when being set.		
10	Red	Reset user settings
This action will delete all user settings on the Danalock. The Danalock will respond by blinking red.		